



Knopf Bouton Knob



	ϕ				
standard	4	20 28 40 1	20 28 40 2	20 28 40 3	20 28 40 4
	6	20 28 60 1	20 28 60 2	20 28 60 3	20 28 60 4
	1/4"	20 28 61 1	20 28 61 2	20 28 61 3	20 28 61 4
mat finish	4	26 28 40 1	26 28 40 2	26 28 40 3	26 28 40 4
	6	26 28 60 1	26 28 60 2	26 28 60 3	26 28 60 4
	1/4"	26 28 61 1	26 28 61 2	26 28 61 3	26 28 61 4




mit Strich — avec repère — with line

	ϕ				
standard	4	21 28 40 1	21 28 40 2	21 28 40 3	21 28 40 4
	6	21 28 60 1	21 28 60 2	21 28 60 3	21 28 60 4
	1/4"	21 28 61 1	21 28 61 2	21 28 61 3	21 28 61 4
mat finish	4	27 28 40 1	27 28 40 2	27 28 40 3	27 28 40 4
	6	27 28 60 1	27 28 60 2	27 28 60 3	27 28 60 4
	1/4"	27 28 61 1	27 28 61 2	27 28 61 3	27 28 61 4

Knebelknopf Bouton à oreilles Wing knob




	ϕ				
standard	4	22 28 40 1	22 28 40 2	22 28 40 3	22 28 40 4
	6	22 28 60 1	22 28 60 2	22 28 60 3	22 28 60 4
	1/4"	22 28 61 1	22 28 61 2	22 28 61 3	22 28 61 4
mat finish	4	28 28 40 1	28 28 40 2	28 28 40 3	28 28 40 4
	6	28 28 60 1	28 28 60 2	28 28 60 3	28 28 60 4
	1/4"	28 28 61 1	28 28 61 2	28 28 61 3	28 28 61 4




mit Strich — avec repère — with line

	ϕ				
standard	4	23 28 40 1	23 28 40 2	23 28 40 3	23 28 40 4
	6	23 28 60 1	23 28 60 2	23 28 60 3	23 28 60 4
	1/4"	23 28 61 1	23 28 61 2	23 28 61 3	23 28 61 4
mat finish	4	29 28 40 1	29 28 40 2	29 28 40 3	29 28 40 4
	6	29 28 60 1	29 28 60 2	29 28 60 3	29 28 60 4
	1/4"	29 28 61 1	29 28 61 2	29 28 61 3	29 28 61 4

Pfeilknopf Bouton à flèche Arrow knob



	ϕ				
standard	6	18 28 60 1	18 28 60 2	18 28 60 3	18 28 60 4
	1/4"	18 28 61 1	18 28 61 2	18 28 61 3	18 28 61 4
mat finish	6	16 28 60 1	16 28 60 2	16 28 60 3	16 28 60 4
	1/4"	16 28 61 1	16 28 61 2	16 28 61 3	16 28 61 4



mit Strich — avec repère — with line

	ϕ				
standard	6	19 28 60 1	19 28 60 2	19 28 60 3	19 28 60 4
	1/4"	19 28 61 1	19 28 61 2	19 28 61 3	19 28 61 4
mat finish	6	17 28 60 1	17 28 60 2	17 28 60 3	17 28 60 4
	1/4"	17 28 61 1	17 28 61 2	17 28 61 3	17 28 61 4