



fischer elektronik


M-210. kép THF 129 TO 220




M-211. kép THF 247 4




M-212. kép THF 409 TO 220




M-213. kép THF 409-220 1



M-214. kép THF 409-220 2




M-215. kép THF 409-32



Cikkszám	Típus	Tokozás	Hűtőborda
35-03-00	THF 129 TO 220	TO 220	FK 222 THF
35-01-57	THF 247 4	TO-220, TOP-3, TO-247, TO-248	SK 460 STC
35-01-48	THF 409 TO 220	TO-220, TOP-3, TO-247, TO-248	SK 409
35-02-87	THF 409-220 1	TO-220, TOP-3, TO-247, TO-248	SK 409, SK 459
35-02-76	THF 409-220 2	TO-220, TOP-3, TO-247, TO-248	SK 145, SK 185, SK 437
35-01-58	THF 409-32	SOT-32, TO-126, SOT-82	SK 409

fischer elektronik

M-216. kép



Cikkszám	Típus	Leírás
35-02-18	ISP 218	TO-218 műanyag leszorító M3-as csavarhoz
35-02-16	ISP 220	TO-220 műanyag leszorító M3-as csavarhoz
35-02-17	ISP 220V	TO-220V műanyag leszorító M3-as csavarhoz
35-02-19	ISP 247	TO-247 műanyag leszorító M3-as csavarhoz